


PART №
6001405



(3) Needle bar, presser bar and driving parts

ITEM	PART NO.	DESCRIPTION	Q'ty	REMARKS
1	6001401	SYNCHRO PULLEY (70 TEETH) FOR N600A,N602A	1	
2	6001402	SCREW, FOR 6001401	2	
3	6001403	RETAINING COLLAR	1	
4	6001404	SCREW, FOR 6001403	2	
5	6001405	SPACER	1	
6	6001224	OIL FELT	1	
7	6001407	MAIN SHAFT	1	
7-1	6001407-1	SCREW	1	
7-2	6001407-2	SCREW	1	
7-3	6001407-3	OIL FELT	1	
8	6001408	CONNECTING ROD ASSEMBLY	1	
9	6001409	CONNECTING ROD SUB-ASSEMBLY	1	
10	6001410	SCREW, FOR CONNECTING ROD CAP	2	
11	6001411	SCREW, FOR ECCENTRIC CAM	1	
12	6001412	WASHER, FOR 6001408	1	
13	6001413	NUT, FOR 6001408 (A-8-S)	1	
14	6001414	ROD END (POS-8)	1	
15	6001415	SCREW, FOR 6001419	1	
16	6001416	WASHER, FOR 6001419	1	
17	6001417	OIL FELT	1	
18	6001418	SPRING	1	
19	6001419	ROD END STUD	2	
21	6001421	NUT, FOR 6001422	2	
22	6001422	ADJUSTING STUD	2	
23	6001423	OIL FELT	2	
24	6001424	NEEDLE BAR LEVER STUD	1	
25	6001425	NEEDLE BAR LEVER ASSEMBLY	2	
26	6001426	SCREW, FOR 6001425	1	
27	6001427	OIL FELT	1	
28	6001428	NEEDLE BAR CONNECTION ASSEMBLY	1	
29	6001429	OIL TUBE	1	
30	6001430	SCREW, FOR 6001428	1	
31	6001431	NEEDLE BAR WITH NUT	1	
32	6001432	NEEDLE CLAMP NUT	1	
33	6001433	NEEDLE (DNX1 #25)	1	
34	6001434	PRESSER FOOT LIFTER BASE	1	
35	6001435	SCREW, FOR 6001434	2	
36	6001436	SCREW, FOR 6001434	1	
37	6001437	PRESSER BAR	1	
38	6001438	PRESSER BAR CONNECTION	1	
39	6001430	SCREW, FOR 6001438	1	
40	6001440	PRESSER SPRING	1	
41	6001441	PRESSER FOOT ASSEMBLY	1	
42	6001442	SCREW	1	
43	6001443	NUT SM 9/64"-40	1	
44	6001444	SCREW, FOR 6001441, 6001445	1	
45	6001445	PRESSER FOOT ASSEMBLY (FOR CE)	(1)	
46	6001446	PRESSER FOOT LIFTER	(1)	
48	6001448	"O" RING	(1)	
50	6001450	SCREW, FOR 6001446	(1)	
51	6001451	SCREW, FOR LIFTER STOPPER	(1)	
52	6001452	SYNCHRO PULLEY (60 TEETH) FOR N600H,N602H	(1)	