







PART №
6001608



(4) Looper driving parts

ITEM	PART NO.	DESCRIPTION	Q'ty	REMARKS
1	6001601	SPRING SUPPORTER BLOCK	1	(2)
2	6001602	SCREW, FOR 6001601	1	
3	6001023	SCREW, FOR 6001601	2	
4	6001604	SPRING SUPPORTER	1	
5	6001605	SPRING	1	
6	6001606	LOOPER ROCKER SHAFT ARM (A)	1	(7)
7	6001435	SCREW, FOR 6001606	1	
8	6001608	ROLLER	1	
9	6001609	ROLLER STUD SCREW	1	
10	6001610	NUT, FOR 6001609	1	
11	6001611	LOOPER ROCKER SHAFT ARM (B)	1	(12)
12	6001612	SCREW, FOR 6001611	1	
13	6001613	LOOPER ROCKER	1	
14	6001415	SCREW, FOR 6001613	1	(14)
15	6001615	LOOPER	1	
16	6001451	SCREW, FOR 6001415	1	
17	6001617	LOOPER ROCKER SHAFT	1	
18	6001618	LOOPER DRIVE CAM	1	(19)
18-1	6001618-1	WASHER	2	
19	6001619	SCREW, FOR 6001618	2	
20	6001224	OIL FELT	1	